

ATmega88/168

Pin	Port	Serial	AD	PWM	Special	Common	Port-Pin	PIN ASSIGN	
14	PB0						din-2	COL-01	出力
15	PB1			OC1A			aout-2		
16	PB2			OC1B			aout-3		
17	PB3			OC2A	MOSI		dout-0		
18	PB4				MISO	Button		Button	入力
19	PB5				SCK	on board LED		LED	出力
9	PB6				XTAL	XTAL		XTAL	
10	PB7				XTAL	XTAL		XTAL	
23	PC0		ADC0				ain-0	COL-02	出力
24	PC1		ADC1				ain-1	COL-03	出力
25	PC2		ADC2				ain-2	COL-04	出力
26	PC3		ADC3				ain-3	COL-05	出力
27	PC4		ADC4				din-0		
28	PC5		ADC5				din-1		
1	PC6				RESET	RESET		RESET	
2	PD0	RXD				USB		USB/D-	
3	PD1	TXD					din-3	ROW-01	入力
4	PD2				INT0	USB		USB/D+	
5	PD3			OC2B			dout-1	ROW-02	入力
6	PD4						dout-2	ROW-03	入力
11	PD5			OC0B			aout-1	ROW-04	入力
12	PD6			OC0A			aout-0	ROW-05	入力
13	PD7						dout-3	ROW-06	入力